

Trying 3106016892...Open

Welcome to STN International! Enter x:x  
LOGINID:sssptal644pnh  
PASSWORD:  
TERMINAL (ENTER 1, 2, 3, OR ?):2

\* \* \* \* \* Welcome to STN International \* \* \* \* \*

NEWS	1		Web Page URLs for STN Seminar Schedule - N. America
NEWS	2	Sep 29	The Philippines Inventory of Chemicals and Chemical Substances (PICCS) has been added to CHEMLIST
NEWS	3	Oct 27	New Extraction Code PAX now available in Derwent Files
NEWS	4	Oct 27	SET ABBREVIATIONS and SET PLURALS extended in Derwent World Patents Index files
NEWS	5	Oct 27	Patent Assignee Code Dictionary now available in Derwent Patent Files
NEWS	6	Oct 27	Plasdoc Key Serials Dictionary and Echoing added to Derwent Subscriber Files WPIDS and WPIX
NEWS	7	Nov 29	Derwent announces further increase in updates for DWPI
NEWS	8	Dec 5	French Multi-Disciplinary Database PASCAL Now on STN
NEWS	9	Dec 5	Trademarks on STN - New DEMAS and EUMAS Files
NEWS	10	Dec 15	2001 STN Pricing
NEWS	11	Dec 17	Merged CEABA-VTB for chemical engineering and biotechnology
NEWS	12	Dec 17	Corrosion Abstracts on STN
NEWS	13	Dec 17	SYNTHLINE from Prous Science now available on STN
NEWS	14	Dec 17	The CA Lexicon available in the CAPLUS and CA files
NEWS	15	Jan 05	AIDSLINE is being removed from STN
NEWS EXPRESS			FREE UPGRADE 5.0e FOR STN EXPRESS 5.0 WITH DISCOVER! (WINDOWS) NOW AVAILABLE
NEWS HOURS			STN Operating Hours Plus Help Desk Availability
NEWS INTER			General Internet Information
NEWS LOGIN			Welcome Banner and News Items
NEWS PHONE			Direct Dial and Telecommunication Network Access to STN
NEWS WWW			CAS World Wide Web Site (general information)

Enter NEWS followed by the item number or name to see news on that specific topic.

All use of STN is subject to the provisions of the STN Customer agreement. Please note that this agreement limits use to scientific research. Use for software development or design or implementation of commercial gateways or other similar uses is prohibited and may result in loss of user privileges and other penalties.

\* \* \* \* \* STN Columbus \* \* \* \* \*

FILE 'HOME' ENTERED AT 12:43:11 ON 24 JAN 2001

=> file medline embase biosis scisearch caplus

COST IN U.S. DOLLARS	SINCE FILE	TOTAL
	ENTRY	SESSION
FULL ESTIMATED COST	0.15	0.15

FILE 'MEDLINE' ENTERED AT 12:43:32 ON 24 JAN 2001

FILE 'EMBASE' ENTERED AT 12:43:32 ON 24 JAN 2001

COPYRIGHT (C) 2001 Elsevier Science B.V. All rights reserved.

FILE 'BIOSIS' ENTERED AT 12:43:32 ON 24 JAN 2001

COPYRIGHT (C) 2001 BIOSIS(R)

FILE 'SCISEARCH' ENTERED AT 12:43:32 ON 24 JAN 2001

COPYRIGHT (C) 2001 Institute for Scientific Information (ISI) (R)

FILE 'CAPLUS' ENTERED AT 12:43:32 ON 24 JAN 2001

USE IS SUBJECT TO THE TERMS OF YOUR STN CUSTOMER AGREEMENT.

PLEASE SEE "HELP USAGETERMS" FOR DETAILS.

COPYRIGHT (C) 2001 AMERICAN CHEMICAL SOCIETY (ACS)

=> s avian antibody

L1 108 AVIAN ANTIBODY

=> s l1 and Escherichia coli H7 strain

L2 0 L1 AND ESCHERICHIA COLI H7 STRAIN

=> s l1 and E coli

L3 0 L1 AND E COLI

=> s l1 and anaerobacteria

L4 0 L1 AND ANAEROBACTERIA

=> s l1 and peptostriptoccus anaerobius

L5 0 L1 AND PEPTOSTRIPTOCUS ANAEROBIUS

=> s l1 and bacteria

L6 2 L1 AND BACTERIA

=> d l6

L6 ANSWER 1 OF 2 BIOSIS COPYRIGHT 2001 BIOSIS

AN 1998:262100 BIOSIS

DN PREV199800262100

TI Antibodies to recombinant Clostridium difficile toxins A and B are an effective treatment and prevent relapse of C. difficile-associated disease

in a hamster model of infection.

AU Kink, John A. (1); Williams, Jim A.

CS (1) Ophidian Pharmaceuticals Inc., 5445 East Cheryl Pkwy., Madison, WI 53711 USA

SO Infection and Immunity, (May, 1998) Vol. 66, No. 5, pp. 2018-2025. ISSN: 0019-9567.

DT Article

LA English

=> d 16 all 1-2

L6 ANSWER 1 OF 2 BIOSIS COPYRIGHT 2001 BIOSIS

AN 1998:262100 BIOSIS

DN PREV199800262100

TI Antibodies to recombinant Clostridium difficile toxins A and B are an effective treatment and prevent relapse of C. difficile-associated disease

in a hamster model of infection.

AU Kink, John A. (1); Williams, Jim A.

CS (1) Ophidian Pharmaceuticals Inc., 5445 East Cheryl Pkwy., Madison, WI 53711 USA

SO Infection and Immunity, (May, 1998) Vol. 66, No. 5, pp. 2018-2025. ISSN: 0019-9567.

DT Article

LA English

AB Clostridium difficile causes antibiotic-associated diarrhea and colitis in

humans through the actions of toxin A and toxin B on the colonic mucosa. At present, broad-spectrum antibiotic drugs are used to treat this disease, and patients suffer from high relapse rates after termination of treatment. This study examined the role of both toxins in pathogenesis

and

the ability of orally administered **avian antibodies** against recombinant epitopes of toxin A and toxin B to treat C difficile-associated disease (CDAD). DNA fragments representing the

entire

gene of each toxin were cloned, expressed, and affinity purified. Hens were immunized with these purified recombinant-protein fragments of toxin A and toxin B. Toxin-neutralizing antibodies fractionated from egg yolks were evaluated by a toxin neutralization assay in Syrian hamsters. The carboxy-terminal region of each toxin was most effective in generating toxin-neutralizing antibodies. With a hamster infection model, antibodies to both toxins A and B (CDAD antitoxin) were required to prevent

morbidity

and mortality from infection. In contrast to vancomycin, CDAD antitoxin prevented relapse and subsequent C. difficile reinfection in the

hamsters.

These results indicate that CDAD antitoxin may be effective in the treatment and management of CDAD in humans.

CC Pharmacology - Immunological Processes and Allergy \*22018

Biochemical Studies - Proteins, Peptides and Amino Acids \*10064

Biochemical Studies - Carbohydrates \*10068

Toxicology - General; Methods and Experimental \*22501

Physiology and Biochemistry of Bacteria \*31000

Immunology and Immunochemistry - General; Methods \*34502

Immunology and Immunochemistry - Bacterial, Viral and Fungal \*34504

Medical and Clinical Microbiology - Bacteriology \*36002

BC Endospore-forming Gram-Positives 07810

IT Major Concepts

Immune System (Chemical Coordination and Homeostasis); Pharmacology

IT Chemicals & Biochemicals

anti-Clostridium difficile toxin A antibody: immunostimulant - drug;

anti-Clostridium difficile toxin B antibody: immunostimulant - drug;

recombinant Clostridium difficile toxin A; recombinant Clostridium

difficile toxin B  
 IT Methods & Equipment  
     in vitro toxin neutralization assay  
 ORGN Super Taxa  
     Endospore-forming Gram-Positives: Eubacteria, **Bacteria**,  
     Microorganisms  
 ORGN Organism Name  
     Clostridium-difficile (Endospore-forming Gram-Positives): pathogen  
 ORGN Organism Superterms  
     **Bacteria**; Eubacteria; Microorganisms

L6 ANSWER 2 OF 2 CAPLUS COPYRIGHT 2001 ACS

AN 1998:635674 CAPLUS

DN 129:259335

TI Use of **avian antibodies**

IN Larsson, Anders; Kollberg, Hans

PA Immunsytem Ims AB, Swed.

SO PCT Int. Appl., 16 pp.

CODEN: PIXXD2

DT Patent

LA English

IC ICM A61K039-40

ICS C07K016-02

CC 15-3 (Immunochemistry)

FAN.CNT 1

	PATENT NO.	KIND	DATE	APPLICATION NO.	DATE
PI	WO 9841235	A1	19980924	WO 1998-SE526	19980320
	W: AL, AM, AT, AU, AZ, BA, BB, BG, BR, BY, CA, CH, CN, CU, CZ, DE, DK, EE, ES, FI, GB, GE, GH, GM, GW, HU, ID, IL, IS, JP, KE, KG, KP, KR, KZ, LC, LK, LR, LS, LT, LU, LV, MD, MG, MK, MN, MW, MX, NO, NZ, PL, PT, RO, RU, SD, SE, SG, SI, SK, SL, TJ, TM, TR, TT, UA, UG, US, UZ, VN, YU, ZW, AM, AZ, BY, KG, KZ, MD, RU, TJ, TM RW: GH, GM, KE, LS, MW, SD, SZ, UG, ZW, AT, BE, CH, DE, DK, ES, FI, FR, GB, GR, IE, IT, LU, MC, NL, PT, SE, BF, BJ, CF, CG, CI, CM, GA, GN, ML, MR, NE, SN, TD, TG				
	SE 9701212	A	19980921	SE 1997-1212	19970403
	SE 511993	C2	20000110		
	AU 9865312	A1	19981012	AU 1998-65312	19980320
	EP 971741	A1	20000119	EP 1998-911344	19980320
	R: AT, BE, CH, DE, DK, ES, FR, GB, GR, IT, LI, LU, NL, SE, MC, PT, IE, FI				
	BR 9808392	A	20000523	BR 1998-8392	19980320
PRAI	SE 1997-1026		19970320		
	WO 1998-SE526		19980320		

AB The present invention relates to use of **avian antibodies** and/or antigen binding fragments thereof, for the prodn. of a drug for treatment and/or prevention of respiratory tract infections. The infection is bacterial, viral or fungal. The drug is administered through local application at the oral cavity and/or pharynx. Antibodies against Pseudomonas aeruginosa was prepd. in and purified from domestic hens for treating Pseudomonas infection.

ST **avian antibody** respiratory tract infection

IT Bacterial infection

Bird (Aves)

Lymph

Mouthwashes

Mycosis  
 Oral drug delivery systems  
 Pharynx  
 Pseudomonas  
 Pseudomonas aeruginosa  
 Pulmonary infection  
 Respiratory tract infection  
 Viral infection  
 (**avian antibodies** for treating respiratory tract  
 infection by **bacteria** or virus or fungus)

IT Antibodies  
 RL: BPN (Biosynthetic preparation); PUR (Purification or recovery); THU  
 (Therapeutic use); BIOL (Biological study); PREP (Preparation); USES  
 (Uses)

(**avian antibodies** for treating respiratory tract  
 infection by **bacteria** or virus or fungus)

IT Antigens  
 RL: BSU (Biological study, unclassified); BIOL (Biological study)  
 (**avian antibodies** for treating respiratory tract  
 infection by **bacteria** or virus or fungus)

IT Chicken (Gallus domesticus)  
 (domestic hens; **avian antibodies** for treating  
 respiratory tract infection by **bacteria** or virus or fungus)

IT Bronchial diseases  
 (infection; **avian antibodies** for treating  
 respiratory tract infection by **bacteria** or virus or fungus)

IT Pharynx  
 (oropharynx; **avian antibodies** for treating  
 respiratory tract infection by **bacteria** or virus or fungus)

=> d his

(FILE 'HOME' ENTERED AT 12:43:11 ON 24 JAN 2001)

FILE 'MEDLINE, EMBASE, BIOSIS, SCISEARCH, CAPLUS' ENTERED AT 12:43:32 ON  
24 JAN 2001

L1 108 S AVIAN ANTIBODY  
 L2 0 S L1 AND ESCHERICHIA COLI H7 STRAIN  
 L3 0 S L1 AND E COLI  
 L4 0 S L1 AND ANAEROBACTERIA  
 L5 0 S L1 AND PEPTOSTRIPTOCCUS ANAEROBIUS  
 L6 2 S L1 AND BACTERIA

=> s l1 and ruminal bacteria

L7 0 L1 AND RUMINAL BACTERIA

=> s E coli H7

L8 17 E COLI H7

=> dup remove l8

PROCESSING COMPLETED FOR L8

L9 6 DUP REMOVE L8 (11 DUPLICATES REMOVED)

=> d 19 all 1-6

L9 ANSWER 1 OF 6 CAPLUS COPYRIGHT 2001 ACS  
AN 1998:207285 CAPLUS  
DN 128:228232  
TI Motility channel pathogen detector and method of use  
IN Wun, Chun Kwun; Torre, Frank J.  
PA Springfield College, USA  
SO U.S., 9 pp.  
CODEN: USXXAM  
DT Patent  
LA English  
IC ICM G01N033-567  
NCL 435007210  
CC 9-1 (Biochemical Methods)  
FAN.CNT 1

	PATENT NO.	KIND	DATE	APPLICATION NO.	DATE
PI	US 5733736	A	19980331	US 1996-767165	19961216
	WO 9827431	A1	19980625	WO 1997-US14156	19970827
	W: AL, AM, AT, AU, AZ, BA, BB, BG, BR, BY, CA, CH, CN, CU, CZ, DE, DK, EE, ES, FI, GB, GE, GH, HU, IL, IS, JP, KE, KG, KP, KR, KZ, LC, LK, LR, LS, LT, LU, LV, MD, MG, MK, MN, MW, MX, NO, NZ, PL, PT, RO, RU, SD, SE, SG, SI, SK, SL, TJ, TM, TR, TT, UA, UG, UZ, VN, YU, ZW, AM, AZ, BY, KG, KZ, MD, RU, TJ, TM				
	RW: GH, KE, LS, MW, SD, SZ, UG, ZW, AT, BE, CH, DE, DK, ES, FI, FR, GB, GR, IE, IT, LU, MC, NL, PT, SE, BF, BJ, CF, CG, CI, CM, GA, GN, ML, MR, NE, SN, TD, TG				
	AU 9742299	A1	19980715	AU 1997-42299	19970827
	EP 956505	A1	19991117	EP 1997-940548	19970827
	R: CH, DE, FR, GB, LI, NL				

PRAI US 1996-767165 19961216  
WO 1997-US14156 19970827

AB A motility channel pathogen detector and method of use of the detector are

disclosed for detecting a target motile pathogen in a test sample of potential pathogens. The motility channel pathogen detector includes: a dish having a base and walls arising from the base to define a motility channel; an anti-serum end of the motility channel; an inoculation end of the motility channel opposed to the anti-serum end; and opposed channel walls that cooperate to define the motility channel between the anti-serum

and inoculation ends of the channel. A growth medium is positioned in the

motility channel and an anti-serum that biol. interacts with the target motile pathogen is positioned in the growth medium in the anti-serum end so that the anti-serum diffuses in the growth medium to form an

anti-serum front between the channel walls. The sample of potential pathogens is inoculated in the growth medium adjacent the inoculation end so that any target motile pathogen moves towards, contacts and accumulates at the anti-serum front to form a visible detection line adjacent the anti-serum front. In one embodiment the target motile pathogen is a serotype of Escherichia coli bacteria generally known as "E. coli 0157:H7", and the anti-serum is E. coli H7 anti-serum which restricts motility of the pathogen.

ST motility channel pathogen detector

IT Peptones  
 RL: BUU (Biological use, unclassified); BIOL (Biological study); USES  
 (Uses)  
 (Protease; motility channel pathogen detector and method of use)

IT Antiserums  
 Culture media  
 Escherichia coli  
 Pathogenic microorganism  
 Sensors  
 (motility channel pathogen detector and method of use)

IT 56-45-1, L-Serine, biological studies 60-00-4, Edta, biological studies  
 63-68-3, L-Methionine, biological studies 302-95-4, Sodium deoxycholate  
 7487-88-9, Magnesium sulfate, biological studies 7790-58-1, Potassium  
 tellurite 9002-18-0, Agar 16068-46-5, Potassium phosphate  
 RL: BUU (Biological use, unclassified); BIOL (Biological study); USES  
 (Uses)  
 (motility channel pathogen detector and method of use)

L9 ANSWER 2 OF 6 MEDLINE DUPLICATE 1  
 AN 97193822 MEDLINE  
 DN 97193822  
 TI Use of the flagellar H7 gene as a target in multiplex PCR assays and  
 improved specificity in identification of enterohemorrhagic Escherichia  
 coli strains.  
 AU Gannon V P; D'Souza S; Graham T; King R K; Rahn K; Read S  
 CS Animal Diseases Research Institute, Agriculture and Agri-Food Canada,  
 Lethbridge, Alberta, Canada.. gannonv@em.agr.ca  
 SO JOURNAL OF CLINICAL MICROBIOLOGY, (1997 Mar) 35 (3) 656-62.  
 Journal code: HSH. ISSN: 0095-1137.  
 CY United States  
 DT Journal; Article; (JOURNAL ARTICLE)  
 LA English  
 FS Priority Journals  
 OS GENBANK-L07338; GENBANK-U47614  
 EM 199708  
 EW 19970801  
 AB PCR products of 1.8 kb were generated with DNAs from all Escherichia coli  
 H7 strains tested by using oligonucleotide primers which flank the fliC  
 gene. Three RsaI digestion profiles of these PCR products were evident on  
 agarose gels; the first occurred with serotype O55:H7, O157:H7, or  
 nonmotile (NM) strains, the second occurred with serotype O1:H7 and  
 O18:H7  
 strains, and the third occurred with serotype O?:H7, O19:H7, O121:H7,  
 O88:H7, and O156:H7 strains. Despite these differences, the nucleotide  
 sequences of the E. coli E32511 (O157:NM) and U5-41 (O1:H7) fliC genes  
 were 97% homologous. Two PCR primer pairs synthesized on the basis of the  
 E32511 H7 fliC sequence amplified specific DNA fragments from all  
**E. coli H7** strains, but did not amplify DNA  
 fragments from the other bacterial strains. The H7-specific primers were  
 used in combination with other primers which target the Verotoxin 1 (VT1)  
 and VT2 genes and the E. coli O157:H7 eaeA gene in multiplex PCR assays.  
 In these assays, vt and eaeA PCR products were observed with DNAs from  
 the  
 majority of EHEC strains and vt, eaeA, and fliC PCR products were  
 observed  
 with DNAs from E. coli O157:H7 or NM strains. Only eaeA PCR products were  
 present with DNA from enteropathogenic E. coli, and only vt PCR products  
 occurred with VT-producing E. coli which are not EHEC. The multiplex PCR

assays described allow for the specific identification of E. coli O157:H7 or NM and other EHEC strains.

CT Check Tags: Animal; Human; Support, Non-U.S. Gov't  
Bacterial Outer Membrane Proteins: GE, genetics  
Bacterial Toxins: GE, genetics  
Base Sequence  
DNA Primers: GE, genetics  
DNA, Bacterial: GE, genetics  
Escherichia coli: CL, classification  
\*Escherichia coli: GE, genetics  
Escherichia coli: IP, isolation & purification  
Escherichia coli Infections: MI, microbiology  
Escherichia coli O157: CL, classification  
Escherichia coli O157: GE, genetics  
Escherichia coli O157: IP, isolation & purification  
\*Flagella: GE, genetics  
Flagellin: GE, genetics  
\*Genes, Bacterial  
Molecular Sequence Data  
\*Polymerase Chain Reaction: MT, methods  
Polymerase Chain Reaction: SN, statistics & numerical data  
Sensitivity and Specificity  
Sequence Homology, Nucleic Acid  
Serotyping  
RN 12777-81-0 (Flagellin); 147094-99-3 (eae protein); 156066-56-7 (FlaC protein)  
CN 0 (Bacterial Outer Membrane Proteins); 0 (Bacterial Toxins); 0 (DNA Primers); 0 (DNA, Bacterial); 0 (Shiga-like toxin I); 0 (Shiga-like toxin II)

L9 ANSWER 3 OF 6 MEDLINE  
AN 97335329 MEDLINE  
DN 97335329  
TI Variation in manifestation of E. coli H7 antigen.  
AU Bailey C W; Carson C A  
CS WHO Collaborating Center for Enteric Zoonoses, College of Veterinary Medicine, University of Missouri, Columbia 65211, USA.  
SO ADVANCES IN EXPERIMENTAL MEDICINE AND BIOLOGY, (1997) 412 83-5.  
Journal code: 2LU. ISSN: 0065-2598.  
CY United States  
DT Journal; Article; (JOURNAL ARTICLE)  
LA English  
FS Priority Journals  
EM 199710  
EW 19971005  
CT Check Tags: Support, Non-U.S. Gov't  
DNA Primers  
\*Escherichia coli O157: GE, genetics  
Escherichia coli O157: IM, immunology  
\*Flagellin: GE, genetics  
Flagellin: IM, immunology  
Genes, Structural, Bacterial  
Polymerase Chain Reaction: MT, methods  
RN 12777-81-0 (Flagellin); 156066-56-7 (FlaC protein)  
CN 0 (DNA Primers)

L9 ANSWER 4 OF 6 MEDLINE  
DUPLICATE 3



AN 96387752 MEDLINE  
 DN 96387752  
 TI Monoclonal antibodies for detection of the H7 antigen of Escherichia coli.  
 AU He Y; Keen J E; Westerman R B; Littledike E T; Kwang J  
 CS U.S. Meat Animal Research Center, U.S. Department of Agriculture, Clay Center, Nebraska 68933, USA.. he@aux.marc.usda.gov  
 SO APPLIED AND ENVIRONMENTAL MICROBIOLOGY, (1996 Sep) 62 (9) 3325-32.  
 Journal code: 6K6. ISSN: 0099-2240.  
 CY United States  
 DT Journal; Article; (JOURNAL ARTICLE)  
 LA English  
 FS Priority Journals  
 EM 199612  
 AB Two murine monoclonal antibodies (MAbs) (2B7 and 46E9-9) reactive with the H7 flagellar antigen of Escherichia coli were produced and characterized. A total of 217 E. coli strains (48 O157:H7, 4 O157:NM, 23 O157:non-H7, 22 H7:non-O157, and 120 non-O157:nonH7), 17 Salmonella serovars, and 29 other gram-negative bacteria were used to evaluate the reactivities of the two MAbs by indirect enzyme-linked immunosorbent assay (ELISA). Both MAbs reacted strongly with all E. coli strains possessing the H7 antigen and with H23- and H24-positive E. coli strains. Indirect ELISA MAB specificity was confirmed by inhibition ELISA and by Western blotting (immunoblotting), using partially purified flagellins from E. coli O157:H7 and other E. coli strains. On a Western blot, MAb 46E9-9 was more reactive against H7 flagellin of E. coli O157:H7 than against H7 flagellin of E. coli O1:K1:H7. Competition ELISA suggested that MAbs 2B7 and 46E9-9 reacted with closely related H7 epitopes. When the ELISA reactivities of the MAbs and two commercially available polyclonal anti-H7 antisera were compared, both polyclonal antisera and MAbs reacted strongly with E. coli H7 bacteria. However, the polyclonal antisera cross-reacted strongly both with non-H7 E. coli and with many non-E. coli bacteria. The polyclonal antisera also reacted strongly with H23 and H24 E. coli isolates. The data suggest the need to define serotype-specific epitopes among H7, H23, and H24 E. coli flagella. The anti-H7 MAbs described in this report have the potential to serve as high-quality diagnostic reagents, used either alone or in combination with O157-specific MAbs, to identify or detect E. coli O157:H7 in food products or in human and veterinary clinical specimens.  
 CT Check Tags: Animal  
 \*Antibodies, Monoclonal: IM, immunology  
 Antibody Specificity  
 \*Antigens, Bacterial: AN, analysis  
 Cross Reactions  
 Enzyme-Linked Immunosorbent Assay  
 \*Escherichia coli: IM, immunology  
 Mice  
 Mice, Inbred BALB C  
 Serotyping  
 CN 0 (Antibodies, Monoclonal); 0 (Antigens, Bacterial)

L9 ANSWER 5 OF 6 MEDLINE

DUPLICATE 4

AN 86086289 MEDLINE

DN 86086289

TI H7 antiserum-sorbitol fermentation medium: a single tube screening medium for detecting Escherichia coli O157:H7 associated with hemorrhagic colitis.

AU Farmer J J 3d; Davis B R

SO JOURNAL OF CLINICAL MICROBIOLOGY, (1985 Oct) 22 (4) 620-5.

Journal code: HSH. ISSN: 0095-1137.

CY United States

DT Journal; Article; (JOURNAL ARTICLE)

LA English

FS Priority Journals

EM 198604

AB Escherichia coli serotype O157:H7 has been isolated from outbreaks and sporadic cases of hemorrhagic colitis. There is convincing evidence that it can cause this diarrheal disease. Because of the interest in hemorrhagic colitis, it has become desirable to detect this particular strain in human feces, which usually contains many other strains of E. coli. Two characteristics of the incriminated E. coli O157:H7 strain have made its isolation and identification easier. It does not ferment D-sorbitol rapidly, in contrast to about 95% of other E. coli strains. In addition, the strain has H antigen 7, but only about 10% of other E. coli strains have this particular antigen. To screen for E. coli O157:H7 we devised H7 antiserum-sorbitol fermentation medium (18 g of enteric fermentation base, 10 g of D-sorbitol, 4 g of agar, 10 ml of Andrade indicator, 989 ml of water; all ingredients were mixed, autoclaved, and cooled; 1 ml of **E. coli H7** antiserum was then added). Colonies to be screened were inoculated into this medium. Strains of E. coli O157:H7 gave a characteristic pattern; they did not ferment sorbitol and were immobilized in the semisolid medium because of the reaction of their flagella with the flagella antiserum. Almost all other strains of E. coli gave a different pattern; they fermented sorbitol

or were not immobilized by the H7 serum or both. Strains which were presumptive positives (sorbitol negative, H7 positive) were then tested

in

E. coli O157 serum by slide or tube agglutination. (ABSTRACT TRUNCATED AT 250 WORDS)

CT Check Tags: Human

Agglutination Tests

\*Antigens, Bacterial: AN, analysis

Antigens, Bacterial: IM, immunology

\*Colitis: MI, microbiology

Culture Media

Escherichia coli: IM, immunology

\*Escherichia coli: IP, isolation & purification

Escherichia coli: ME, metabolism

\*Escherichia coli Infections: MI, microbiology

False Positive Reactions

\*Feces: MI, microbiology

Fermentation

Flagella: IM, immunology

\*Gastrointestinal Hemorrhage: MI, microbiology

Immune Sera

\*Sorbitol: ME, metabolism

Species Specificity

RN 50-70-4 (Sorbitol)

CN 0 (Antigens, Bacterial); 0 (Culture Media); 0 (H antigen)

L9 ANSWER 6 OF 6 EMBASE COPYRIGHT 2001 ELSEVIER SCI. B.V.  
 AN 85238836 EMBASE  
 DN 1985238836  
 TI H7 antiserum-sorbitol fermentation medium: A single tube screening medium for detecting Escherichia coli O157:H7 associated with hemorrhagic colitis.  
 AU Farmer III J.J.; Davis B.R.  
 CS Enteric Bacteriology Section, Center for Infectious Diseases, Centers for Disease Control, Atlanta, GA 30333, United States  
 SO Journal of Clinical Microbiology, (1985) 22/4 (620-625).  
 CODEN: JCMIDW  
 CY United States  
 DT Journal  
 FS 004 Microbiology  
 026 Immunology, Serology and Transplantation  
 048 Gastroenterology  
 LA English  
 AB Escherichia coli serotype O157:H7 has been isolated from outbreaks and sporadic cases of hemorrhagic colitis. There is convincing evidence that it can cause this diarrheal disease. Because of the interest in hemorrhagic colitis, it has become desirable to detect this particular strain in human feces, which usually contains many other strains of E. coli. Two characteristics of the incriminated E. coli O157:H7 strain have made its isolation and identification easier. It does not ferment D-sorbitol rapidly, in contrast to about 95% of other E. coli strains. In addition, the strain has H antigen 7, but only about 10% of other E. coli strains have this particular antigen. To screen for E. coli O157:H7 we devised H7 antiserum-sorbitol fermentation medium (18 g of enteric fermentation base, 10 g of D-sorbitol, 4 g of agar, 10 ml of Andrade indicator, 989 ml of water; all ingredients were mixed, autoclaved, and cooled; 1 ml of E. coli H7 antiserum was then added). Colonies to be screened were inoculated into this medium. Strains of E. coli O157:H7 gave a characteristic pattern; they did not ferment sorbitol and were immobilized in the semisolid medium because of the reaction of their flagella with the flagella antiserum. Almost all other strains of E. coli gave a different pattern; they fermented sorbitol or were not immobilized by the H7 serum or both. Strains which were presumptive positives (sorbitol negative, H7 positive) were then tested in E. coli O157 serum by slide or tube agglutination. The number of strains which were presumptive positive by H7-sorbitol medium but then were not found to be O157 was less than 1%. A second approach has been helpful in deciding which colonies to screen in H7-sorbitol medium. MacConkey-sorbitol agar (22.2 g of MacConkey agar base [which contains no sugar], 10 g of D-sorbitol, 1,000 ml of water) was designed as a plating medium. Stools were plated on MacConkey agar to estimate the number of E. coli colonies and also plated on MacConkey-sorbitol agar to estimate the number of sorbitol-negative colonies of E. coli. These two approaches have proved useful for isolating and identifying E. coli O157:H7 from human feces and from feces of animals infected in the laboratory with this strain. The results suggest that media may be formulated in a similar fashion for detecting other specific strains of E. coli.  
 CT Medical Descriptors:  
 \*escherichia coli

\*fermentation  
 \*h antigen  
 \*ulcerative colitis  
 culture medium  
 feces  
 food  
 large intestine  
 priority journal  
 diagnosis  
 in vitro study  
 nonhuman  
 digestive system  
 Drug Descriptors:  
 \*sorbitol  
 shiga toxin

RN (sorbitol) 26566-34-7, 50-70-4, 53469-19-5; (shiga toxin) 75757-64-1

=> s P anaerobius

L10 204 P ANAEROBIUS

=> dup remove l10

PROCESSING COMPLETED FOR L10

L11 91 DUP REMOVE L10 (113 DUPLICATES REMOVED)

=> s l11 and cattle

L12 3 L11 AND CATTLE

=> d l12 all 1-3

L12 ANSWER 1 OF 3 MEDLINE

AN 97076913 MEDLINE

DN 97076913

TI An rRNA approach for assessing the role of obligate amino acid-fermenting bacteria in ruminal amino acid deamination.

AU Krause D O; Russell J B

CS Section of Microbiology, Cornell University, Ithaca, New York 14853, USA.

SO APPLIED AND ENVIRONMENTAL MICROBIOLOGY, (1996 Mar) 62 (3) 815-21.  
Journal code: 6K6. ISSN: 0099-2240.

CY United States

DT Journal; Article; (JOURNAL ARTICLE)

LA English

FS Priority Journals

EM 199703

EW 19970301

AB Ruminal amino acid degradation is a nutritionally wasteful process that produces excess ruminal ammonia. Monensin inhibited the growth of monensin-sensitive, obligate amino acid-fermenting bacteria and decreased the ruminal ammonia concentrations of **cattle**. 16S rRNA probes indicated that monensin inhibited the growth of *Peptostreptococcus anaerobius* and *Clostridium sticklandii* in the rumen. *Clostridium aminophilum* was monensin sensitive in vitro, but *C. aminophilum* persisted in the rumen after monensin was added to the diet. An in vitro culture

system was developed to assess the competition of *C. aminophilum*, *P. anaerobius*, and *C. sticklandii* with predominant ruminal bacteria (PRB). PRB were isolated from a 10(8) dilution of ruminal fluid and maintained as a mixed population with a mixture of carbohydrates. PRB did not hybridize with the probes to *C. aminophilum*, *P. anaerobius*, or *C. sticklandii*. PRB deaminated Trypticase in continuous culture, but the addition of *C. aminophilum*, *P. anaerobius*, and *C. sticklandii* caused a more-than-twofold increase in the steady-state concentration of ammonia. *C. aminophilum*, *P. anaerobius*, and *C. sticklandii* accounted for less than 5% of the total 16S rRNA and microbial protein. Monensin eliminated *P. anaerobius* and *C. sticklandii* from continuous cultures, but it could not inhibit *C. aminophilum*. The monensin resistance of *C. aminophilum* was a growth rate-dependent, inoculum size-independent phenomenon that could not be maintained in batch culture. On the basis of these results, we concluded that the feed additive monensin cannot entirely counteract the wasteful amino acid deamination of obligate amino acid-fermenting ruminal bacteria.

CT Check Tags: Animal; Female; Support, Non-U.S. Gov't  
 \*Amino Acids: ME, metabolism  
 Cattle  
 Clostridium: IP, isolation & purification  
 \*Clostridium: ME, metabolism  
 Deamination  
 Fermentation  
 Monensin: PD, pharmacology  
 Peptostreptococcus: IP, isolation & purification  
 \*Peptostreptococcus: ME, metabolism  
 Rumen: ME, metabolism  
 \*Rumen: MI, microbiology  
 RNA Probes  
 \*RNA, Ribosomal, 16S

RN 17090-79-8 (Monensin)  
 CN 0 (Amino Acids); 0 (RNA Probes); 0 (RNA, Ribosomal, 16S)

L12 ANSWER 2 OF 3 MEDLINE  
 AN 93152452 MEDLINE  
 DN 93152452  
 TI Phylogeny of the ammonia-producing ruminal bacteria *Peptostreptococcus anaerobius*, *Clostridium sticklandii*, and *Clostridium aminophilum* sp. nov.  
 AU Paster B J; Russell J B; Yang C M; Chow J M; Woese C R; Tanner R  
 CS Forsyth Dental Center, Boston, Massachusetts 02115.  
 NC DE-04881 (NIDCR)  
 DE-08303 (NIDCR)  
 SO INTERNATIONAL JOURNAL OF SYSTEMATIC BACTERIOLOGY, (1993 Jan) 43 (1) 107-10.  
 Journal code: AWO. ISSN: 0020-7713.  
 CY United States  
 DT Journal; Article; (JOURNAL ARTICLE)  
 LA English  
 FS Priority Journals  
 OS GENBANK-L04166; GENBANK-L04168; GENBANK-L04167; GENBANK-M59107; GENBANK-M59084; GENBANK-M23927; GENBANK-M26494; GENBANK-M59090; GENBANK-M59083; GENBANK-M23929; GENBANK-M59095  
 EM 199305  
 AB In previous studies, gram-positive bacteria which grew rapidly with

peptides or an amino acid as the sole energy source were isolated from bovine rumina. Three isolates, strains C, FT (T = type strain), and SR, were considered to be ecologically important since they produced up to 20-fold more ammonia than other ammonia-producing ruminal bacteria. On the basis of phenotypic criteria, the taxonomic position of these new isolates was uncertain. In this study, the 16S rRNA sequences of these isolates and related bacteria were determined to establish the phylogenetic positions of the organisms. The sequences of strains C, FT, and SR and reference strains of *Peptostreptococcus anaerobius*, *Clostridium sticklandii*, *Clostridium coccoides*, *Clostridium aminovalericum*, *Acetomaculum ruminis*, *Clostridium leptum*, *Clostridium lituseburense*, *Clostridium acidurici*, and *Clostridium barkeri* were determined by using a modified Sanger dideoxy chain termination method. Strain C, a large coccus purported to belong to the genus *Peptostreptococcus*, was closely related to *P. anaerobius*, with a level of sequence similarity of 99.6%. Strain SR, a heat-resistant, short, rod-shaped organism, was closely related to *C. sticklandii*, with a level of sequence similarity of 99.9%. However, strain FT, a heat-resistant, pleomorphic, rod-shaped organism, was only distantly related to some clostridial species and *P. anaerobius*. On the basis of the sequence data, it was clear that strain FT warranted designation as a separate species. The closest known relative of strain FT was *C. coccoides* (level of similarity, only 90.6%). Additional strains that are phenotypically similar to strain FT were isolated in this study. (ABSTRACT TRUNCATED AT 250 WORDS)

CT Check Tags: Animal; Comparative Study; Female; Support, Non-U.S. Gov't; Support, U.S. Gov't, Non-P.H.S.; Support, U.S. Gov't, P.H.S.  
 \*Ammonia: ME, metabolism  
 Cattle  
 \*Clostridium: CL, classification  
 Clostridium: IP, isolation & purification  
 \*Clostridium: ME, metabolism  
 Molecular Sequence Data  
 \*Peptostreptococcus: CL, classification  
 Peptostreptococcus: IP, isolation & purification  
 \*Peptostreptococcus: ME, metabolism  
 Phylogeny  
 \*Rumen: MI, microbiology  
 RN 7664-41-7 (Ammonia)

L12 ANSWER 3 OF 3 BIOSIS COPYRIGHT 2001 BIOSIS

AN 2000:450419 BIOSIS

DN PREV200000450419

TI The isolation, characterization and enumeration of hyper-ammonia producing ruminal bacteria.

AU Russell, J. B. (1); Rychlik, J. L.

CS (1) Department of Microbiology, Cornell University, Ithaca, NY, 14853 USA

SO Asian-Australasian Journal of Animal Sciences, (July, 2000) Vol. 13, No. Special Issue, pp. 121-127. print.  
 ISSN: 1011-2367.

DT Article

LA English

SL English

AB Ruminal amino acid deamination is a wasteful process that often produces

more ammonia than bacteria can utilize. Some carbohydrate-fermenting ruminal bacteria can deaminate amino acids, but these species have specific activities of ammonia production that are lower than mixed ruminal bacteria. In the 1980's and 1990's, bacteria that could not utilize carbohydrates were isolated from the rumen, and these bacteria could deaminate amino acids at a very rapid rate and grow rapidly on peptides and amino acids. Based on 16S RNA sequences, the American isolates were identified as *Peptostreptococcus anaerobius*, *Clostridium sticklandii*, and *Clostridium aminophilum*. New Zealand workers recently isolated a bacterium phylogenetically similar to *P.*

*anaerobius*, but other isolates were more closely related to *Peptostreptococcus asaccharolyticus*, *Eubacterium nodatum* and

#### Fusobacterium

*necrophorum*. Mixed ruminal bacteria from **cattle** fed grain produced ammonia half as fast as bacteria from **cattle** fed hay, and a mathematical model predicted that grain-fed **cattle** would have fewer hyper-ammonia producing bacteria than hay-fed **cattle**. When mixed bacteria from **cattle** fed hay were incubated at acidic pH, the ammonia production decreased, and some hyper-ammonia producing bacteria are sensitive to acidic pH. Most hyper-ammonia producing

#### bacteria

are monensin sensitive, and monensin decreased the ruminal ammonia concentration of **cattle** fed hay. However, *C. aminophilum* grows with relatively high concentrations of monensin in vitro, and 16S rRNA probes indicated that monensin (350 mg/day) did not eliminate this bacterium from the rumen. Hyper-ammonia-producing bacteria are nutritionally detrimental, and additional avenues are needed to decrease their numbers in the rumen.

- CC Animal Production - Feeds and Feeding \*26504
  - Biochemical Studies - General \*10060
  - Biochemical Studies - Proteins, Peptides and Amino Acids \*10064
  - Biochemical Studies - Carbohydrates \*10068
  - Metabolism - General Metabolism; Metabolic Pathways \*13002
  - Nutrition - General Studies, Nutritional Status and Methods \*13202
  - Digestive System - Physiology and Biochemistry \*14004
  - Reproductive System - Physiology and Biochemistry \*16504
  - Animal Production - General; Methods \*26502
  - Animal Production - Breeds and Breeding \*26506
  - Physiology and Biochemistry of Bacteria \*31000
- BC Bacteria - General Unspecified 05000
  - Bacteroidaceae 06901
  - Gram-Positive Cocci 07700
  - Endospore-forming Gram-Positives 07810
  - Irregular Nonsporing Gram-Positive Rods 08890
- IT Major Concepts
  - Animal Husbandry (Agriculture); Metabolism; Nutrition
- IT Parts, Structures, & Systems of Organisms
  - rumen: digestive system
- IT Chemicals & Biochemicals
  - 16S RNA; 16S rRNA probe; amino acids: deamination; ammonia: production;
  - carbohydrate: fermentation; monensin; peptides
- IT Methods & Equipment
  - 16S RNA sequencing: analytical method, molecular genetics method;
  - hyper-ammonia bacteria production model: mathematical model
- IT Miscellaneous Descriptors
  - grain: animal feed; hay: animal feed; pH
- ORGN Super Taxa

Artiodactyla: Mammalia, Vertebrata, Chordata, Animalia; Bacteria:  
 Microorganisms; Bacteroidaceae: Anaerobic Gram-Negative Rods,  
 Eubacteria, Bacteria, Microorganisms; Endospore-forming  
 Gram-Positives:  
 Eubacteria, Bacteria, Microorganisms; Gram-Positive Cocci: Eubacteria,  
 Bacteria, Microorganisms; Irregular Nonsporing Gram-Positive Rods:  
 Actinomycetes and Related Organisms, Eubacteria, Bacteria,  
 Microorganisms  
 ORGN Organism Name  
 Clostridium aminophilum (Endospore-forming Gram-Positives);  
 Clostridium  
 sticklandii (Endospore-forming Gram-Positives); Eubacterium nodatum  
 (Irregular Nonsporing Gram-Positive Rods); Fusobacterium necrophorum  
 (Bacteroidaceae); Peptostreptococcus anaerobius (Gram-Positive Cocci);  
 Peptostreptococcus asaccharolyticus (Gram-Positive Cocci);  
 hyper-ammonia producing bacteria (Bacteria); ruminant (Artiodactyla)  
 ORGN Organism Superterms  
 Animals; Artiodactyls; Bacteria; Chordates; Eubacteria; Mammals;  
 Microorganisms; Nonhuman Mammals; Nonhuman Vertebrates; Vertebrates  
 RN 7664-41-7 (AMMONIA)  
 17090-79-8 (MONENSIN)

=>

---Logging off of STN---

=>

Executing the logoff script...

=> LOG Y

COST IN U.S. DOLLARS	SINCE FILE	TOTAL
	ENTRY	SESSION
FULL ESTIMATED COST	52.36	52.51
DISCOUNT AMOUNTS (FOR QUALIFYING ACCOUNTS)	SINCE FILE	TOTAL
	ENTRY	SESSION
CA SUBSCRIBER PRICE	-1.18	-1.18

STN INTERNATIONAL LOGOFF AT 12:50:47 ON 24 JAN 2001